



The configured network License Sever needs to be updated before this application will run.

ALPHACAM





```
USB:\Utilities(Network License)\License Manager
Installation\setup.exe
```